SYSTEM/MODEL: NEM

MODIFICATION: Call tone annunciation during monitoring mode


DIFFICULTY LEVEL: 3 - Moderate - Removal or replacement of internal components.


COMPONENTS REQUIRED: N/A

- INSTR/OPERATIONS: 1. Locate VIOLET wire in upper left corner of PC-356. (Looking at the solder side of the board with operation panel opened forward). Verify its location by locating junction of R45, "-" side of C23, and base of Tr11 in the same corner, and trace to VIOLET wire.
 - 2. Remove wire from PC board.
 - 3. This modification will allow the call tone and LED to activate when a sub calls in while the master has another sub station selected.

REFERENCE DRAWING #: 0998-620, 356-620

CALL TONE ANNUNCIATION DURING MONITORING MODE (When sub station places a call)





Cut VIOLET wire from main PC board. (Located in corner near RY5, upper left corner of solder side when Operation Panel is open.)