
TWO LEM-1DL MASTER STATIONS WITH ONE SUB STATION



NOTES:

- 1. Install the bare wire end of the DAK-2S component module to "1" terminal of the LEM-1DL masters.
- 2. Only one master can be used at a time.
- 3. Each master MUST have its own power supply. Otherwise, ground loop feedback will occur when either master station is on.