

AC Series - Triple Swipe Configuration


Introduction

AC Nio provides a feature to configure a Triple Swipe of a credential to perform a specific action.


Hardware - Doors

Navigate to the **Hardware** section in the left-hand menu and select **Doors**.

This will display a list of all doors configured to the system.



In the top menu, select the reader that the triple swipe function will be enabled for. Navigate to the bottom of the screen and check the checkbox to enable the triple swipe feature. Once the checkbox is enabled, click the pencil icon to attach an action when the Triple Swipe feature is initiated.



Click the dropdown arrow to scroll through a list of available actions. After the conditions are set, click the **X** in the top right hand corner to close the window and click **Save**.

