


Reducing Chime Volume

Introduction

This guide explains how to reduce the chime volume of IX Series stations. The settings for door and master stations are configured separately.

Door Station Settings

Open **IX Support Tool**. Navigate to **Station Settings**, Volume / Tone. Scroll right to the Receive column. Click on the cell for the appropriate door station, and use the dropdown menu to select the desired volume level on a scale from 1 to 10. Click **Update**.




| Transmit | Receive |
|----------|---------|
| | |
| | |
| | |
| 10 | 6 |
| 10 | 10 |
| 10 | 1 |
| 10 | 2 |
| 10 | 3 |
| 10 | 4 |
| 10 | 5 |
| 10 | 6 |
| 10 | 7 |
| 10 | 8 |
| 10 | 9 |
| 10 | 10 |

i The Receive volume controls the spoken audio produced at the door station as well as the chime volume. Be careful not to set it too low.

Completely Muting the Door Station Chime

Sometimes it may be preferable to not have a chime at all when the door station calls out. Open **IX Support Tool**. Navigate to **Call Settings**, Call Origination. Click the cell for the door station under Ringback Tone. Set the option to **None** and click **Update**.




| Ringback Tone |
|----------------|
| Call Pattern 4 |
| |
| Call Pattern 4 |
| Call Pattern 1 |
| Call Pattern 1 |
| None |
| Call Pattern 1 |
| Call Pattern 2 |
| Call Pattern 3 |
| Call Pattern 4 |
| Call Pattern 5 |
| Call Pattern 6 |
| Tremolo Sound |

i The "None" option is not available for IX-BA or IX-DA door stations.

Master Station Settings


Navigate to **Station Settings**, Volume / Tone. Scroll right to the Ringtone column. Click on the cell for the desired master station, and use the drop-down menu to select the volume level on a scale from 0 to 10. Click **Update**.



A vertical dropdown menu titled "Ringtone" with a blue header. The menu is open, showing a list of numbers from 0 to 10. The number 6 is highlighted with a blue background and a red border, indicating it is the selected option.

Uploading Settings to Stations

Navigate to **File** and select Upload Settings to Stations. Select all stations and click **Settings** to upload settings to stations.



The "Setting File Upload" dialog box is shown. It features a "Station List" table with columns for "Select", "Number", "Name", "Location", "Station Type", and "Status". The first row (0001) is selected. Below the table, there is a "Select Station by Type:" dropdown set to "All" and "Select" and "Unselect" buttons. At the bottom, there are four buttons for "Settings", "Sounds", "Image", and "Schedule". An orange hand icon points to the "Settings" button.

| Select | Number | Name | Location | Station Type | Status |
|-------------------------------------|--------|-----------------|----------|-------------------|--------|
| <input checked="" type="checkbox"/> | 0001 | Master Station1 | | IX-MV7.* | - |
| <input type="checkbox"/> | 0002 | Master Station2 | | IX-MV7.* | - |
| <input type="checkbox"/> | 0003 | Master Station3 | | IX-MV7.* | - |
| <input type="checkbox"/> | 0004 | Master Station4 | | IX-MV7.* | - |
| <input type="checkbox"/> | 0005 | Master Station5 | | IX-MV7.* | - |
| <input type="checkbox"/> | 0006 | Master Station6 | | IX-MV | - |
| <input type="checkbox"/> | 0007 | Video Station1 | | IX-DV, IX-DVF(-*) | - |
| <input type="checkbox"/> | 0008 | Video Station2 | | IX-DV, IX-DVF(-*) | - |
| <input type="checkbox"/> | 0009 | Video Station3 | | IX-DA | - |
| <input type="checkbox"/> | 0010 | Audio Station1 | | IX-SS, 2G | - |