



PRODUCT DRAWING




MOUNTING



DESCRIPTION SUB STATION (Color monitor)	FIG. NAME PRODUCT DRAWING	UNIT mm	DATE 11 November, 2004
MODEL NO. KB-3HRD	FIG.NO. 40037301-1-3	PAGE 1/3	REVISION 1
AIPHONE			

WIRING DIAGRAM



Observe that each two Sub stations (#1 & 2, and #3 & 4) are powered by a separate Power supply. (KB-3MRD Master station is always powered by a single Power supply, not combined with Sub stations).

On the last Sub station (KB-3HRD), put Impedance switch to left (TERMINATED) position.

Assign the Station #2~5 on each KB-3HRD Sub station.

The switch bank A, B, C is located inside the chassis.

RESTRICTIONS

KB-3HRD is compatible with KB-3MRD Master station system only.

Avoid installing KB-3HRD in the following locations;

- Places under direct sunlight or near heating equipment that varies in temperature.
- Places subject to iron dust, dust, oil, chemicals, hydrogen sulfide (hot spring), etc.
- Places subject to moisture and humidity extremes, such as bathroom, cellar, greenhouse, etc.
- Places where the temperature is quite low, such as inside a refrigerated area or in front of air-conditioner.
- Places subject to steam or smoke (heating or cooking surfaces)

The Restrictions on wiring for the Master station shall be met.

DESCRIPTION SUB STATION (Color monitor)	FIG. NAME WIRING/RESTRICTIONS	UNIT mm	DATE 4 March, 2003
MODEL NO. KB-3HRD	FIG.NO. 40037301-2-3	PAGE 2/3	REVISION 2
AIPHONE			


FUNCTIONS

Call-in from Door stations, Visualization of a caller and communication
 (Chime tone from each Door station & call-in LED steadily lit)
 Instant on audio together with image, before lifting handset to reply
 Monitor video and audio of selected door, by pressing Door MONITOR button
 Call a Sub station selectively with a Selector button. It sounds double pre-tone and call by voice direct. (All Call button flashing, turns steadily lit upon answered)
 Open voice simultaneous communication at the called station
 (Privacy mode can be set to prevent eavesdropping)
 All Call by pressing ALL CALL button once. It sounds single pre-tone and call by voice direct. (All Call button flashing, turns steadily lit upon answered)
 While answering door, depress and hold down Door release button to activate door strike (Door release button is steadily lit)
 Tilt the door camera up or down by pressing top or bottom of Tilt control pad.

SETTING


On SET switches below Directory card;

- Chime tone cut-off for each door (SW1~3).
- White light LED auto on or off (SW4).
- The LED turns on automatically when the door station is put into low light conditions.



On the SET switches inside chassis;

- Set for Station # 1~5 with three DIP switches A~C.
- Terminate on the last Station with the DIP switch.



- Adjust door audio monitor volume OFF MID HIGH with MONITOR switch (bottom, right).
- Adjust (1) chime tone and (2) handset voice volume with TONE control. (on front panel)
 - (1) In standby; STANDARD HIGH LOW.
 - (2) While communicating; STANDARD HIGH VERY HIGH.
- Set for privacy mode or release. In standby, press ALL CALL button for 2 sec. or more. ("ALL CALL" lit green)
- Adjust brightness of monitor screen. (bottom, left)
- Place the station in privacy mode. Press ALL CALL button for 2 sec. or more (while in standby mode). Operate same way to release.

DESCRIPTION SUB STATION (Color monitor)	FIG. NAME FUNCTIONS/SETTING	UNIT mm	DATE 4 March, 2003
MODEL NO. KB-3HRD	FIG.NO. 40037301-3-3	PAGE 3/3	REVISION 2
AIPHONE			