

MODIFICATION DIAGRAM

NEM ADD-ON SELECTOR SUPPLEMENT

**Connecting new Add-On Selector to an older NEM master
or Connecting new NEM master to an older Add-On**

Connect the new NEM or Add-On Selector to the Plug on
the old NEM or Add-On Selector master as shown below

New NEM / Add-On Selector
Terminals / Wires

Brown (X1)
Red (X2)
Orange (X3)
Yellow (X4)
Green (X5)
Blue (X6)
Violet (X7)
Gray (X8)
White (H)
Black (E)

Old NEM / Add-On
Selector Plug

Orange (3)
Brown (1)
Red (2)
Green (5)
Violet (7)
White (9)
Black (10)
Grey (8)
Yellow (4)
Blue (6)

